




Essential T1041



max. load
100 kg / 220 lbs





EN Mounting instructions
DE Montageanleitung
FR Consignes d'installation
NL Montagevoorschrift
ES Instrucciones de montaje

IT Istruzioni di montaggio
PT Manual de montagem
EL Οδηγίες συναρμολόγησης
SV Montageföreskrifter
PL Instrukcja montażu

RU Инструкция по сборке и установке
CZE Návod k montáži
SK Návod na montáž
HU Szerelési előírás
TR Montaj kılavuzu

RO Instrucțiuni de montaj
UK Вказівки по монтажі
BG Инструкции за монтаж
JA 設置の説明書
ZH 装配说明



12	A		M8x16	18	L		4	W		1
	B		M6x12	4	M		1			
	C		M6x8	4	N		1			
	D		M6x12	2	O		1			
	E		M8x30	8	P		1	A1		4
	F		D8	18	Q		1	A2		4
	G		M6	2	R		1	A3		4
	H			1	S		1	A4		4
	I		5mm + I1 4mm	1+1	T		1	A5		4
	J		(8-10) + J1 (17-19)	1+1	U		1	A6		4
	K			4	V		2	A7		4